



**Instruction**

MI 021-388  
September 1996

**I/A Series<sup>®</sup> Magnetic Flow Transmitter  
Model IMT25**

**with Integral Keypad and Display**

**Local Operation, Configuration, and Calibration**



A Siebe Group Company



# Contents

<b>Figures.....</b>	<b>v</b>
<b>Tables.....</b>	<b>vi</b>
<b>1. Introduction.....</b>	<b>1</b>
Description .....	1
Intended Audience .....	1
Functions .....	1
Reference Documents .....	2
<b>2. Quick Start.....</b>	<b>3</b>
Determination of Meter Factor for IMT25 .....	5
<b>3. Operation.....</b>	<b>7</b>
Keypad/Display Panel .....	7
Alarm and Diagnostic Messages .....	8
Acknowledging Alarms .....	11
Write Protect Switch .....	12
Resetting Totals and Empty Pipe Count .....	12
Viewing and Changing Data .....	12
On-Line Help .....	14
Top Level Menu .....	14
Measurements Mode .....	15
Status Mode .....	16
Identity Mode .....	18
Setup Mode .....	18
<b>4. Configuration.....</b>	<b>21</b>
Configuration Procedure .....	21
System Setup .....	22
Default Screen .....	22
Dual Display .....	22
Rate Display .....	22
Rate EGU .....	22

Rate Format .....	23
Rate Damping .....	23
Totalizer .....	24
Tots EGU .....	24
Tot/Net Format .....	24
Gr Tot Format .....	24
Reset Totals .....	25
Setup of Outputs .....	25
Output Mode .....	25
Range Info .....	25
Pulse Out .....	26
Rate Out Damp .....	26
Relay Out 1 and Relay Out 2 .....	26
Setup of Alarms .....	27
High Rate and Low Rate .....	27
High Fwd Tot 1 and High Fwd Tot 2 .....	27
Empty Pipe .....	27
Rate Response .....	27
Display Respon .....	28
Alarm Clear .....	28
Setup of Diagnostics .....	28
Rate Response .....	28
Display Respon .....	28
Setup of Identity .....	28
Setup of Passcodes .....	29
Setup of Transmitter .....	29
Xmtr Mode .....	29
Line Frequency .....	29
Flow Direction .....	30
Contact Input 1 and Contact Input 2 .....	30
Noise Reduction .....	31
Empty Pipe Detection .....	31
Setup of Calibration .....	31
Meter Factor .....	32
Analog Out Cal .....	32
Preset Outputs .....	32
<b>Appendix A. Structure Diagrams .....</b>	<b>33</b>
<b>Appendix B.</b>	
<b>Configuration Worksheets .....</b>	<b>49</b>
<b>Index .....</b>	<b>59</b>

# Figures

1	IMT25 Magnetic Flow Transmitter — Keypad/Display .....	7
2	IMT25 Magnetic Flow Transmitter — Displays .....	8
3	Example of Structure Diagram .....	13
4	Top Level Menu Summary .....	14
5	Noise Reduction .....	31
A-1	Structure Diagram – Top Level Menu .....	33
A-2	Structure Diagram – Measurements Menu .....	34
A-3	Structure Diagram – Status Menu .....	35
A-4	Structure Diagram – Identity Menu .....	36
A-5	Structure Diagram – Setup Menu .....	37
A-6	Structure Diagram – System Menu .....	38
A-7	Structure Diagram – System Menu (Cont.) .....	39
A-8	Structure Diagram – Outputs Menu .....	40
A-9	Structure Diagram – Outputs Menu (Cont.) .....	41
A-10	Structure Diagram – Outputs Menu (Cont.) .....	42
A-11	Structure Diagram – Alarms Menu .....	43
A-12	Structure Diagram – Diagnostics Menu .....	44
A-13	Structure Diagram – Identity Menu .....	44
A-14	Structure Diagram – Passcodes Menu .....	45
A-15	Structure Diagram – Transmitter Menu .....	46
A-16	Structure Diagram – Transmitter Menu (Cont.) .....	47
A-17	Structure Diagram – Calibration Menu .....	48

# Tables

1	Reference Documents .....	2
2	Functions of Keys .....	8
3	Alarm and Diagnostic Messages .....	9
4	Reason Codes .....	9
5	Contact Input Status .....	17
6	Relay Output Status .....	17
7	Alphanumeric Characters .....	23
8	Custom Slope .....	23
9	Custom Slope .....	24
10	Function of Output Relays .....	26
11	Flow Direction .....	30
12	Contact Input Functions .....	30

# 1. Introduction

## Description

An I/A Series Magnetic Flowmeter System consists of two major components:

- ◆ IMT25 Magnetic Flow Transmitter
- ◆ Magnetic Flowtube (8000 or 8000A wafer body, or 2800, 8300, or 9300A flanged body)

A system may be specified with the transmitter integrally mounted with the flowtube or with a remote mounted transmitter, which can be mounted either on a pipe or a flat surface.

An IMT25 Transmitter can be operated, configured, and calibrated locally from the transmitter optional keypad/display or remotely from a Model HHT Hand-Held Terminal, an I/A Series Workstation, or the PC10 Configurator.

This document describes local operation and configuration of an IMT25 Transmitter supplied with local keypad and display. For information on remote operation, configuration, and calibration, refer to the documents listed in “Reference Documents” on page 2.

## Intended Audience

This document is intended for use by process operators, engineers, and instrument technicians. If you are interested only in operation, read the general information in the *Introduction* and the chapter titled *Operation*. If you are interested in calibration, read the *Introduction* and chapters titled *Operation* and *Calibration*. If you are concerned with configuration, read the entire manual, with special emphasis on the chapter titles *Configuration* and the structure diagrams in Appendix A and the configuration worksheets in Appendix B.

## Functions

Using the IMT25 front panel keypad/display, the functions you can perform are:

### Operating Functions

- ◆ Display measurement information  
(The current value of: Flow Rate in engineering units (EGU), Flow Rate in % of upper range value (URV), Forward Total, Reverse Total, Net Total, and Grand Total)
- ◆ Display current status or values of transmitter parameters  
(Operating mode, outputs, contact inputs, relay outputs, empty pipe data, noise reduction, and write protection)
- ◆ Display identity information  
(Tag number, location, tag name, device name, and transmitter, flowtube, and software identification data)

- ◆ Acknowledge Alarms
- ◆ Reset Totals (if authorized by passcode assignment)
- ◆ Reset Empty Pipe Counter

### Calibration Functions

---

*NOTE: These functions can be passcode protected.*

---

- ◆ Adjust the 4 and 20 mA output signal (requires additional equipment)
- ◆ Preset outputs to calibrate control loop

### Configuration Functions

---

*NOTE: These functions can be passcode protected.*

---

- ◆ Read, enter, and modify all configuration parameters
- ◆ Assign passcodes and set levels of privilege

## Reference Documents

This document addresses operation, configuration, and calibration using the local keypad/display panel. For remote communication with your transmitter and other details of the flowmeter, refer to the applicable documents listed in Table 1.

*Table 1. Reference Documents*

Document	Description
Refer to I/A Series System Integrated Control Software Documentation	Remote Configuration and Operation from an I/A Series System
MI 021-380	8000A Series Flowtubes, Ceramic Lined, Installation
MI 021-381	8300 Series Flowtubes, Installation
MI 021-386	9300A Series Flowtubes, Flanged, Installation
MI 021-387	IMT25 Transmitter, Installation and Wiring
MI 021-389	IMT25 Transmitter, Operation/Configuration/Calibration using Hand-Held Terminals with FOXCOM Communications Software
MI 021-391	IMT25 Transmitter, 8000A/9300A Flowtube, System Maintenance
MI 020-479	PC10 Configurator
TI 27-71f	Magnetic Flowtubes, Material Selection Guide
TI 027-072	Electrical Conductivity of Process Liquids



## 2. Quick Start


Your IMT25 Transmitter has been preconfigured at the factory to the settings shown in Appendix B. Compare your needs to the factory configuration and note the changes to the configuration you will have to make.

When you power up your transmitter, the display will read:

1 TOP LEVEL  
Measurements

To make changes to the configuration, go to 1 TOP LEVEL Setup by pressing the Down arrow key three times. The procedure to change your configuration will be demonstrated with the example of a process requiring an EGU rate display in GPM, an analog output, a forward unidirectional range of 0 to 150.0 GPM, and a meter factor of 18.22. To make the required configuration changes:

1. In the Default Screen section of Appendix B, note that the factory Rate Display is already configured as GPM, so no change is required.
2. In the 3 OUTPUTS section of Appendix B, note that you may have to change the Output Mode from digital to analog. To do this:
  - a. Go to Setup Level 2 by pressing the Right arrow key. Next move to 2 SETUP Outputs with the down arrow key. Then move to 3 OUTPUTS Output Mode with the Right arrow key.



- b. Use the Right arrow key to move to OUTPUT MODE? {Digital}. The curly brackets indicate that the Digital status is editable. See Figure A-8 for a pictorial representation of this and other output changes.
- c. Press the Shift + Change key to enter Edit mode. You will be asked “Go Off-Line?” Reply yes by pressing the right arrow key. The display will show OUTPUT MODE? [Digital]. The plain brackets show that you are in edit mode.
- d. Press the Down arrow key to display Analog and press the Right arrow key to enter this selection. The display will read OUTPUT MODE? {Analog}. Press the key again to return to 3 OUTPUTS Output Mode.

3. Also in the 3 OUTPUTS section of Appendix B, note that the factory Output Mode is also already configured as UniDir, so no change in the direction is required.
4. You will have to enter your flow upper range value however. To do this:
  - a. Use the Down arrow key to go to 3 OUTPUTS Range Info and the right arrow key to go to FORWARD URV? {#####.# GPM}.
  - b. Press the Shift + Change key to enter Edit mode. The display will show FORWARD URV? [#####.# GPM].
  - c. Use the Right arrow key to move the cursor under the first digit. Use the Down arrow key to scroll the character list until the 0 appears. Use the Right arrow to move the cursor under the second digit. Scroll the list to find the 0. Select the 1, 5, 0, and 0 in a like manner. The display now reads the required URV of 00150.0 GPM.
  - d. Using the Right arrow key, move the cursor under the right bracket and press the key to enter the URV. The display will read FORWARD URV? {150.0 GPM}.
  - e. Press the key again to move back to 3 OUTPUTS Range Info.
5. Lastly, you have to enter your flowmeter factor. To do this:
  - a. Use the Left arrow key to move to the Level 2 menu, 2 SETUP Outputs.
  - b. Press the Down arrow key six times to move to 2 SETUP Calibration and the right arrow key to move to the Level 3 menu, 3 CALIBRATION Meter Factor. See Figure A-5.
  - c. Use the Right arrow key to move to METER FACTOR? {#.#####e+##}.
  - d. Use the Right arrow key to move the cursor under the first digit. Use the Down arrow key to scroll the character list until the 1 appears. Use the Right arrow to move the cursor under the second digit. Scroll the list to find the 8. Select the 2, 2, 0 and 0 and 1 in a like manner. The display now reads the required meter factor of 1.8220.e+01.
  - e. Using the right arrow key, move the cursor under the right bracket and press the key to enter the meter factor. The display will read METER FACTOR? {1.8220E+01}.
  - f. Press the Right arrow key again. The display will read 3 CALIBRATION Meter Factor.
6. Now that all changes have been made, press the Left arrow key until you are asked "Go On-Line?" Reply yes by pressing the Right arrow key.

## Determination of Meter Factor for IMT25

First find the “CAL FACTOR” or “IMT25 CAL FACT” on the flowtube data label.

If the tube data label has a “IMT25 CAL FACT.” listing, use that value as “METER FACTOR.”

If only a “CAL FACTOR” value is found on the flowtube data label, that value must be multiplied by the appropriate factor from the following table to calculate “METER FACTOR.”

8300 Tubes			8000A and 9300A Tubes			
Line Size (in)	M.S. Code	Multiply by Factor	Line Size (in)	M.S. Code	M.S. Code	Multiply by Factor
			0.062	801SA	931SA	1.0034
			0.125	801QA	931QA	1.0033
			0.25	801EA	931EA	1.0011
0.5	830H	0.9938	0.5	800HA	930HA	1.0032
1	830I	0.9967	1	8001A	9301A	1.0011
1.5	831H	0.9960	1.5	801HA	931HA	0.9976
2	8302	0.9964	2	8002A	9302A	0.9985
3	8303	0.9974	3	8003A	9303A	0.9996
4	8304	0.9961	4	8004A	9304A	0.9981
6	8306	0.9947	6	8006A	9306A	1.0001
8	8308	0.9946				
10	8310	0.9941				
12	8312	0.9948				
14	8314	0.9945				
16	8316	0.9943				
18	8318	0.9950				
20	8320	0.9954				
24	8324	0.9962				

Example:

A (3-inch) 8303-... tube with only “CAL FACTOR” listed:

i.e., CAL FACTOR = 7.2911

8303 “MULTIPLY BY FACTOR” = 0.9974


METER FACTOR = 7.2911 \* 0.9974 = 7.2722



# 3. Operation

## Keypad/Display Panel

For local operation, configuration, and calibration, all operator entries are made through a 5-button keypad and all data is presented on a 2-line x 16 character LCD display. The keypad/display of the IMT25 Transmitter is shown in Figure 1. Information on various types of display is shown in Figure 2.




**Figure 1. IMT25 Magnetic Flow Transmitter — Keypad/Display**

All required functions are accomplished by using the four arrow keys alone and in combination with the Shift key. Table 2 explains the function of each key.

**Table 2. Functions of Keys**

Key	Function
Δ	Move up in the product structure. Scroll up in menu, list of characters, or on-line Help message.
Shift + Δ	Reset totals and empty pipe count.
∇	Move down in the product structure. Scroll down in menu, list of characters, or on-line Help message.
Shift + ∇	Acknowledge alarm or diagnostic messages.
◁	Move to the left in the product structure. Cancel parameter selection or data entry.
Shift + ◁	Access on-line Help.
▷	Move to the right in the product structure . Enter parameter selection or data entry.
Shift + ▷	Access Edit mode.



**Figure 2. IMT25 Magnetic Flow Transmitter — Displays**

## Alarm and Diagnostic Messages

The IMT25 will display the Alarm/Diagnostic icon in the upper right of the display if a problem occurs. Identification of the problem is given in one of several alarm or diagnostic messages in Status mode. These are summarized in Table 3 and Table 4:

**Table 3. Alarm and Diagnostic Messages**

Code	Message	Explanation
0100	Invalid Multirange	Reconfigure with a valid multirange.
0116	CoilLow	Transmitter unable to generate a reliable measurement of either the electrode voltage or the coil current. See maintenance instruction (MI 021-391) for additional information.
0117	CoilHigh	
0118	CoilUnstable	
0119	ElecHigh	
0120	ElecUnstable	
0121	ElecLow	
0122	EmptyUnstable	
0128	EmptyUnableToCal	
0131	PulsesLagTotal	Totalizer putting out pulses at the maximum rate but falling behind the actual total. Reconfigure totalizer display format so that each pulse represents a larger volume.
0223	AlarmHighFlow	Flow above configured high flow rate.
0224	AlarmLowFlow	Flow below configured low flow rate.
0225	AlarmHighFwdTotalOne	Total above configured High Fwd Tot 1.
0226	AlarmHighFwdTotalTwo	Total above configured High Fwd Tot 2.
0227	AlarmEmptyPipe	Pipe is empty.

In addition, other problems could be identified on your display in Status mode in the form of a four digit code on line 1 and a five digit code on line 2 of your display. Interpretation of the five digit Reason codes are found in Table 4.

**Table 4. Reason Codes**

Code	Interpretation
00000	No error; transmitter is functioning normally.
00256 - 02559	Memory or computational error; contact Field Service.
02560	An error has occurred in the program storage area, or a code download did not succeed. If you are performing a code upgrade, repeat the procedure. If error persists, contact Field Service.
03072 - 03327 except: 03159, 03169, 03170, 03175, 03176, 03183, 03191, 03193	There is an error in the transmitter configuration. Either a value is out of range, or it is incompatible with other parameters. Make note of the exact number being displayed and contact Field Service.
03159	Illegal analog output URV(s).
03169	Output mode flow direction and transmitter flow direction do not agree.

**Table 4. Reason Codes (Continued)**

Code	Interpretation
03170	Illegal meter factor configured.
03175	Illegal analog output URV(s).
03176	Illegal analog output URV(s).
03183	Pulse URV equals zero.
03191	Output mode configured multi-range, but Contact Input 1 is not configured multi-range.
03193	Output mode configured multi-range, but Contact Input 2 is not configured multi-range.
03328 - 03583 except: 03330, 03332	An error occurred during the configuration process and the transmitter does not trust the configuration information. Step through the menu and edit any selections which might be incorrect. If they are all correct, change one anyway, following the standard edit procedure and then change it back to the desired value.
03330	Configuration error during mode change or 4-20 mA. Change Output Mode from analog to digital (or vice versa), then change it back to the desired state. It is not necessary to go online between changes, but it is necessary to go into and out of the edit mode, as follows: <ol style="list-style-type: none"> <li>1. Brackets around the mode change from { } to [ ] when you press Shift+Right Arrow and go from display to edit mode.</li> <li>2. Change the mode with the up or down arrow key. At this point, the mode may not be what you want, but press the right arrow key to accept the new value anyway. The brackets change back to { }.</li> <li>3. Repeat the cycle if the mode is not the desired one.</li> </ol> At this point, the change flag in the transmitter is set and the CRC will be recalculated when the transmitter is put back online.
03332	Configuration error (such as that caused by a power failure during configuration). To correct the error, you must change a parameter (such as default display) in the main block, using the method described above in 03330.
03584 - 03840	If reasons in this range are displayed, follow the “acknowledge alarm” procedure to see if any other codes exist. Correct the faults indicated by any other codes. If this doesn’t clear all codes, contact Field Service.
04096 - 04607	The fundamental flow tube measurements are incorrect. Contact Field Service.
04608 - 05119	If reasons in this range are displayed, follow the “acknowledge alarm” procedure to see if any other codes exist. Correct the faults indicated by any other codes. If this doesn’t clear all codes, contact Field Service.
05120 - 05887	Hardware error; contact Field Service.
05888 - 07423	If reasons in this range are displayed, follow the “acknowledge alarm” procedure to see if any other codes exist. Correct the faults indicated by any other codes. If this doesn’t clear all codes, contact Field Service.
07424 - 07936	Hardware error; contact Field Service.




**Table 4. Reason Codes (Continued)**

Code	Interpretation
07937 - 08191	An unexpected processor reset has occurred. This might result from an external condition such as a voltage transient. Verify correct operation. If this error persists, contact Field Service.
08192 - 08959	If reasons in this range are displayed, follow the “acknowledge alarm” procedure to see if any other codes exist. Correct the faults indicated by any other codes. If this doesn’t clear all codes, contact Field Service.
08960 - 09471	Hardware error; contact Field Service.
09472 - 09727	If reasons in this range are displayed, follow the “acknowledge alarm” procedure to see if any other codes exist. Correct the faults indicated by any other codes. If this doesn’t clear all codes, contact Field Service.
09728 - 10230	An error has occurred in the digital communications. This may have resulted from a noisy electronic environment or improper installation. Refer to MI 020-350, Wiring Guidelines for Foxboro Intelligent Transmitters, and correct any deficiencies in the field wiring. Contact Field Service if the condition persists.
10240 - 10495	An error has occurred in writing the total to nonvolatile storage. The transmitter may otherwise be operating normally and the displayed and reported totals are correct, but the total will not be saved correctly if the processor is reset. Contact Field Service.
10496	Hardware error; contact Field Service.
10752	Transmitter is performing a reset prior to accepting the download of a new code image.
11776 - 12031	If reasons in this range are displayed, follow the “acknowledge alarm” procedure to see if any other codes exist. Correct the faults indicated by any other codes. If this doesn’t clear all codes, contact Field Service.
12032 - 12288	Transmitter is in the process of performing a requested reset. This reason may be seen if the configuration is being changed. It is not abnormal.
12289 - 13823	Communications error; see above explanation of reasons 09728 - 10239.
13824 and up	If reasons in this range are displayed, follow the “acknowledge alarm” procedure to see if any other codes exist. Correct the faults indicated by any other codes. If this doesn’t clear all codes, contact Field Service.

## Acknowledging Alarms

Whenever an alarm or diagnostic error condition occurs, the Alarm/Diagnostic icon will appear in the upper right of your display.



If you have configured Display Respon as Blink, the display will blink.

To acknowledge the alarm or diagnostic, press the Shift + Ack (∇) key. This action acknowledges the error condition and clears the error history buffer. You may first wish to view an explanation of the problem in Status mode. If you acknowledge the error in Status Alarm or Status Diagnostic, each of the errors in the history buffer will appear on the display for one second before being cleared from the buffer. A contact input may also be configured to acknowledge an alarm. If so, the buffer is also cleared by the contact input.

## Write Protect Switch

The unit is shipped with the Write Protect Switch in the disable position, which disables write protection and permits you to make configuration changes. Refer to MI 021-387 for a more detailed description of this switch.

If you have difficulty making changes, check to see if the switch is in the disable position.

## Resetting Totals and Empty Pipe Count

To reset Fwd Tot (forward total), Rev Tot (reverse total), and Net Tot (net total) to zero, go to Net Tot in Measurements mode and press Shift + Reset (Δ). If Reset Totals is passcode protected, the message ENTER PASSCODE appears. Enter the passcode to proceed.

To reset Gr Tot (grand total) to zero, go to Gr Tot in Measurements mode and press Shift + Reset (Δ). If Reset Totals is passcode protected, the message ENTER PASSCODE appears. Enter the passcode to proceed.

If write protection is enabled, you cannot reset any totals. You must move the Write Protect switch to the disable position and then turn power off and on to disable write protection.


To reset Empty Pipe Count, go to Empty Pipe Cnt in Status mode and press Shift + Reset (Δ).

## Viewing and Changing Data

In Setup (configuration) mode, you will need to move through a structure of parameters (using the arrow keys) to view and/or change the value or status of a particular parameter. Structure diagrams, located in Appendix A, will aid you in doing this.

The Up- and Down-arrow keys will also enable you to scroll through a menu in either direction. You may do this one position at a time or continuously through a menu or string of values by holding the key in the depressed position.

The following example will show you how to use the keys in moving through the structure and in editing several parameters. For the example, we will configure the transmitter for a pulse rate URV of 150.7 GPM at a rate maximum frequency of 5000 Hz. In following this procedure, refer to Figure 3. We will begin at the Level 3 Output menu.



**Figure 3. Example of Structure Diagram**

1. Use the Down arrow key to move from Output Mode to Range Info to Pulse Out Mode.
2. Use the Right arrow key to move to PULSE OUT MODE? {Off}. The curly brackets indicate that the Off status is editable.
3. Press the Shift + Change key to enter Edit mode. If you are not already Off-Line, the display will ask “Go Off-Line?” Reply yes by pressing the Right arrow key. The display will show PULSE OUT MODE? [Off]. The plain brackets indicate that you are in Edit mode.
4. Use the Down arrow key to scroll through the menu. Stop at Pulse Rate. Press the Right arrow key to enter this selection. The display will show PULSE OUT URV? {#####.# GPM}.
5. Press the Shift + Change key to enter Edit mode. The display will show PULSE OUT URV? [#####.# GPM]. The cursor will be under the left bracket.
6. Use the Right arrow key to move the cursor under the first digit. Use the Down arrow key to scroll the character list until the 0 appears. Use the Right arrow to move the cursor under the second digit. Scroll the list to find the 0. Select the 1, 5, 0, and 7 in a like manner. The display now reads the pulse rate required in our example.
7. Using the Right arrow key, move the cursor under the right bracket and press the key twice to enter our pulse rate and move to the next parameter. The display will change to {00150.7 GPM} and then to RATE MAX FREQ? {1000 Hz}.
8. Press the Shift + Change key to enter Edit mode. The display will show RATE MAX FREQ? [1000 Hz].

9. Use the Down arrow key to scroll the menu until 5000 Hz appears. Press the Right arrow key once to enter our selection and a second time to return to Pulse Out Mode. Use the arrow keys to go to the next parameter to be changed.

## On-Line Help

Context-sensitive on-line help messages can be displayed by pressing Shift+Help key. The message displayed pertains directly to the parameter currently displayed on the screen. A typical Help screen is shown below.


```
This is a typical
HELP message ▼
```

The down arrow icon indicates that more information is available. Press the Down arrow key to display the additional information. Similarly, an up arrow icon indicates more information can be displayed by pressing the Up arrow key. To exit from the On-Line Help mode, press either the Left or Right arrow keys. Press the Shift + Help key while in On-Line Help to get help on the On-Line Help function.

## Top Level Menu

The Top Level menu displays four modes – Measurements, Status, Identity, and Setup. You can switch from one to another in sequence by using the Up/Down arrow keys. To enter the second level menu from a particular top level screen, press the Right arrow key. To return to the top level from a second level menu item, press the Left arrow key. The level of the first, second, third, and fourth level menus is indicated by the digit appearing as the first character in Line 1 of the display; a 1 indicates Level 1 (Top Level), a 2 indicates Level 2, and a 3 indicates Level 3, etc.

The top level menu is shown in Figure 4. For a complete presentation of all menu structures, refer to Appendix A.



*Figure 4. Top Level Menu Summary*

## Measurements Mode

The Measurements mode is your main operating mode and it is displayed upon startup. It has six parameters:

- ◆ RATE (EGU): Shows current flow rate (forward or reverse) in the selected engineering units.
- ◆ RATE (% Range): Shows current flow rate (forward or reverse) as a percentage of full scale URV.
- ◆ FWD TOT: Shows current value of the forward totalized flow in engineering units. Use the Net Tot display to reset.

---

*NOTE: If the Totalizer function is configured OFF, the display will read FWD TOT OFF*

---

- ◆ REV TOT: Shows current value of the reverse totalized flow in engineering units. Use the Net Tot display to reset.

---

*NOTE: If the Totalizer function is configured OFF, the display will read REV TOT OFF*

---

- ◆ NET TOT: Shows current value of the net totalized flow (Fwd Tot - Rev Tot) in selected engineering units. If the Reset Totals function is *not* passcode protected, press Shift + Reset ( $\Delta$ ) to reset the displayed total to zero. Resetting Net Tot also resets Fwd Tot and Rev Tot. It does not reset Gr Tot. If Reset Totals is passcode protected, the message ENTER PASSCODE appears.

---

*NOTE: If the Totalizer function is configured OFF, the display will read NET TOT OFF*

---

- ◆ GRAND TOT: Shows current value of the grand total flow in engineering units. If the Reset Totals function is not passcode protected, press Shift + Reset ( $\Delta$ ) to reset the displayed total to zero. Resetting Gr Tot does not reset Fwd Tot, Rev Tot, and Net Tot. If Reset Totals is passcode protected, the message ENTER PASSCODE appears.

---

*NOTE: If the Totalizer function is configured OFF, the display will read GRAND TOT OFF*

---

If the Dual Display feature is configured ON, a combination of two of these parameters can be displayed at once. A typical dual display, in which Line 1 shows flow rate and Line 2 shows the present forward total, is shown below. Note that the units are not displayed.

+35.67 +12345.8
--------------------

You may step through the displays of each of these parameters with the Up- and Down arrow keys. However, unless you specifically do so, the display defaults to that configured in Setup

mode. The engineering units and formats used in the displays are also configured in Setup mode.

The structural diagram of the Measurements menu is located on Figure A-2 of Appendix A on page 34.

## Status Mode

The Status mode enables you to view fourteen system parameters and thus assess the performance of the loop. You may not edit them in this mode. To step through the displays of the following parameters, use the up/down arrow keys:

- ◆ **MODE:** Shows the present operating mode: On-Line, Off-Line, Override, or Calibrate. This will normally display On-Line. The other modes will only be displayed if someone else has changed the mode with an HHT Hand-Held Terminal, PC10 Configurator, or I/A Series Workstation. Off-Line means that it has been taken off-line; Override, that the measurements cannot be relied upon because one or more of the outputs is at a preset value; and Calibrate, that the transmitter is in Calibration mode.
- ◆ **ALARM:** Shows the most current active alarm. If there are no active alarms but something is in the history buffer, the display reads ALARMS IN BUFFER. If there are no active alarms and nothing in the buffer, display reads NO ALARMS.
- ◆ **DIAGNOSTICS:** Shows the most current active diagnostic. If there are no active diagnostics but something is in the history buffer, the display reads DIAGS IN BUFFER. If there are no active diagnostics and nothing in the buffer, display reads NO DIAG.
- ◆ **DIGITAL OUTPUT:** If the transmitter output is set to Digital output mode, the display shows whether the transmitter is configured for Unidirectional or BiDirectional flow. If Digital output mode is not selected, the screen is not displayed.

---

***NOTE: Digital and Analog Output are mutually exclusive. Only one of the two will be displayed at any one time.***

---

- ◆ **ANALOG OUTPUT:** If the transmitter output is set to Analog output mode, the display shows whether the transmitter is configured for U (unidirectional), U/M1 (unidirectional multirange-range 1, U/M2 (unidirectional multirange-range 2, U/M3 (unidirectional multirange-range 3, B/D (bidirectional dual range), or B/S (bidirectional split range). If Analog output mode is not selected, the screen is not displayed.

---

### ***NOTES:***

- 1. Digital and Analog Output are mutually exclusive. Only one of the two will be displayed at any one time.***
  - 2. For definition of direction and range, see “Output Mode” on page 25.***
- 

- ◆ **PULSE OUTPUT:** Shows Off, Pulse Rate or Pulse Total depending on configuration.
- ◆ **CONTACT IN 1:** Shows the current state of Contact Input 1. The possible states are as shown in Table 5.

**Table 5. Contact Input Status**

Display	Interpretation
Off	Contact Input configured Off.
Inactive	There are no Ack Alarm, Reset Totals, or Signal Lock actions taking place.
Invalid	Multi-Range is configured for one contact input and not the other, or both contacts are off.
Ack Alarm	Contact is acknowledging an alarm.
Reset Net Tot	Contact is resetting Fwd Tot, Rev Tot, and Net Tot.
Reset Gr Tot	Contact is resetting Gr Tot.
Reset All Tot	Contact is resetting All Totals
Signal Lock	Contact has “locked” the outputs (fully downscale)
Multi-Range	Contact is configured to switch ranges.

- ◆ CONTACT IN 2: Similar to CONTACT IN 1.
- ◆ RELAY OUT 1: Shows the current function of Relay Output 1. The possible functions are shown in Table 6.

**Table 6. Relay Output Status**

Display	Interpretation
Off	Relay Output configured Off.
Inactive	No alarm or diagnostic conditions are activating the Relay Output.
Forward Dir	Flow in forward direction.
Reverse Dir	Flow in reverse direction.
High Rate Alm	High Rate Alm has activated the Relay Output.
Low Rate Alm	Low Rate Alm has activated the Relay Output.
High Tot 1 Alm	High Tot 1 Alm has activated the Relay Output.
High Tot 2 Alm	High Tot 2 Alm has activated the Relay Output.
Empty Pipe Alm	Empty Pipe Alm has activated the Relay Output.
Diagnostics	One of the diagnostics has activated the Relay Output.

- ◆ RELAY OUT 2: Similar to RELAY OUT 1.
- ◆ EMPTY PIPE DET: The intent of the Empty Pipe Detection feature is explained in “Empty Pipe Detection” on page 31.  
If the empty pipe detector is configured On, the display shows FULL or EMPTY.  
If this feature is configured Off, the display reads OFF.

---

***WARNING: Do not take any action that can cause danger to personnel or damage to equipment based on the assumption that a pipe is empty or full because of an Empty Pipe Detection indication.***

---

- ◆ EMPTY PIPE CNT: Shows the cumulative count (maximum of 255) of empty pipe conditions that have occurred since the last reset. To reset the count to zero, press Shift + Reset ( $\Delta$ ).
- ◆ NOISE REDUCTION: Shows whether the noise reduction function is configured ON or OFF.
- ◆ WRITE PROTECTION: Shows whether the Write Protection dip switch is in the ON position so that *no* Setup (configuration) changes may be made. This feature is usually only used in custody transfer applications or for another reason that the user wants to assure that the configuration will not be changed. For procedure to change the setting of this switch, see MI 021-387.

The structural diagram of the Status menu is located on Figure A-3 of Appendix A on page 35.

## Identity Mode

The Identity mode enables you to view the identity parameters. You may not edit them in this mode. To step through the list of the following parameters, use the Up and Down arrow keys.

TAG NUMBER

LOCATION

TAG NAME (displayed only if in Digital Output mode)

DEVICE NAME (displayed only if in Digital Output mode)

XMTR MS CODE (transmitter model code)

XMTR SERIAL NUM (transmitter serial number)

TUBE MS CODE (flowtube model code)

TUBE SERIAL NUM (flowtube serial number)

SOFTWARE VER (software version)

On strings over 16 characters, left and right arrow icons indicate that there are off screen characters. Use the Left and Right arrow keys to view these characters.

TUBE MS CODE 8302-SATA-TSJ-GF	▶
----------------------------------	---

The structural diagram of the Identity menu is located on Figure A-4 of Appendix A on page 36.

## Setup Mode

The Setup mode enables you to configure your system, output, alarm, diagnostic, identity, passcode, transmitter, and calibration parameters. This is an off-line mode. Outputs will be driven fully upscale or downscale as configured. Upon attempts to enter this mode, you will be warned that you are going off-line and will be asked if you want to do so. Indicate your reply with the left or right arrow keys.

Go Off-Line? ◀ No      Yes ▶
---------------------------------



This can also be a passcode protected mode. So after the initial configuration, you may need a password to enter this mode.

---

*NOTE: If you lose your passcode, call Foxboro for assistance.*

---

For detailed instructions on how to configure your transmitter, see “Configuration” on page 21. The structural diagram of the Setup menu begins with Figure A-5 of Appendix A on page 37.

I



# 4. Configuration

## Configuration Procedure

Several tools have been provided to assist you in configuring the IMT25 transmitter. The structure diagrams in Appendix A provide a road map for moving around within the various menus. Using the structure diagrams, you can determine what you want to do and how to get there to do it.

The second major tool you can use is the configuration worksheets contained in Appendix B. The worksheets provide, in tabular form, a description of each menu item, the available options and, where applicable, the limits for parameter value entries, the normal factory default setting, a space for you to record your own entries, and space for remarks and notes.

Before configuring your transmitter, you should assemble a list of data entry items. Some of the information can be obtained from instrument data plates and/or documents shipped with the instrument. Other data should be calculated based on process information and application requirements. With this list, you can quickly fill in the configuration worksheets and then, using the structure diagrams, operate the keypad/display to make the actual entries.

The items you will have to obtain, decide, and/or calculate are:

- ◆ Analog or Digital mode
- ◆ Flow direction and engineering units
- ◆ Desired resolution of flow rate and totalizer display
- ◆ Unidirectional or BiDirectional and type of range (if analog output)
- ◆ Upper Range Values (URVs) for each range
- ◆ Pulse rate acceptable to external receiver equipment (if so configured)
- ◆ Calculated value of flow volume per pulse (if so configured)
- ◆ Damping factor
- ◆ Relay Output Functions – what you want each output to do and whether the relay will be normally open (NO) or normally closed (NC).
- ◆ The maximum value expected for each totalizer. (Calculate by multiplying the maximum flow rate times the maximum period of totalization.)
- ◆ Alarm functions, setpoints, deadbands
- ◆ Diagnostic functions, response to be taken on a diagnostic, action of the display on a diagnostic function
- ◆ Instrument data (tag number, name, location, tube MS code and serial number, Transmitter MS code and serial number, software version)
- ◆ Passcodes, persons authorized, level of authorization
- ◆ Transmitter initial operating mode, line frequency
- ◆ Contact input functions, status, and operation (NO/NC)
- ◆ Noise reduction setting (on/off)
- ◆ Empty pipe detection (on/off)
- ◆ Flowtube meter factor

## System Setup

The structural diagram of the System menu is located on Figure A-6 and Figure A-7 of Appendix A beginning on page 38.

### Default Screen

The first item to be considered in setting up your system is to decide what display you want your system to default to in Measurements mode. Your choices are:

- Rate in engineering units
- Rate in percent of range
- Forward Total
- Reverse Total
- Net Total
- Grand Total

or a Dual Display of any two of the above if Dual Display is configured ON (see next section).

### Dual Display

In configuring this parameter, first you need to decide whether you want to use the dual display mentioned immediately above. If you selected the Dual Display as your Default Screen, you *must* configure this parameter On. If you want to scroll to a Dual Display sometimes in Measurement mode, you should also configure it On. If you never intend to use it, configure it Off.

If you configure the Dual Display On, you must select the display for Line 1 and for Line 2. You may pick these from the first six choices that were available for the Default Screen.

### Rate Display

#### *Rate EGU*

In the Rate EGU parameter specify the engineering units in which you want your flowrate to be displayed. You may pick from a menu of:

- GPM (gallons per minute)
- GPH (gallons per hour)
- GPD (gallons per day)
- LPM (litres per minute)
- LPH (litres per hour)
- LPD (litres per day)
- Custom Units

If you select Custom Units you must enter the Custom Units you desire in up to six alphanumeric characters. The characters that may be used are listed in Table 7.

**Table 7. Alphanumeric Characters**

Characters
0 through 9
A through Z
a through z
. (period)
+
-
*
/
(space)

You must also enter the conversion factor from gallons per minute to the custom units under Custom Slope. The slope for some frequently used units are given in Table 8. The slope may be from  $1.0e^{-30}$  to  $1.0e^{+30}$ . Enter it in the form  $+#.####e+##$ .

**Table 8. Custom Slope**

Unit	Slope
ft <sup>3</sup> /min	1.3368e-1
m <sup>3</sup> /min	3.7900e-3
bbl/min*	2.3810e-2
ImpGal/min	8.3267e-1

\* 42 gallon barrel

Slope is the quantity of the custom unit that equals one gallon per minute; i.e.,  $0.00379 \text{ m}^3/\text{min} = 1 \text{ GPM}$ . Therefore, 0.00379 is the slope.

---

**NOTE:** To convert to units/hour, multiply the factor in the table by 60. To convert to units/day, multiply the factor in the table by 1440.

---

### Rate Format

In Rate Format, from the eight choices in the menu, select the format of your rate from rounding to the nearest thousand to the nearest ten thousandth of a unit.

---

**NOTE:** Changing this parameter can affect other parameters such as Range URV and Alarm Setpt. For example, if Rate Format was configured as xxxx.xx and the Hi Alm Setpt as 1234.56 but then the Rate Format was changed to xxx.xxx. When you access Alm Setpt again, you will find the display reading 999.999, meaning that the Hi Alm Setpt exceeded the maximum legal limit. The displayed value is the maximum allowable value, **not** the currently configured value.

---

### Rate Damping

In Rate Damping, specify the damping response time for the local display only. It is used to minimize flickering of the less significant digits. Choices are from 00.0 to 99.9 seconds. 00.0 is no damping.

## Totalizer

If you are going to use the Totalizer feature, configure the Totalizer On; if not configure it Off. If you configure it On, specify the engineering units of the totals (Tots EGU), the format of Forward, Reverse, and Net Total (Tot/Net Format), and the format of Grand Total (Gr Tot Format).

### Tots EGU

Specify the engineering units as Gallons, Litres, or Custom Units. If you selected Custom Units in Tots EGU, specify the Custom Units and Custom Slope as you did in Rate EGU. The slope for some frequently used units are given in Table 8. The slope may be from  $1.0e^{-10}$  to  $1.0e^{+10}$ . Enter it in the form  $+\#.####e+\#\#$ .

---

*NOTE: Changing the totalizer EGU rescales all totals to the new engineering units. Changing this parameter can change the total to zero if the total exceeds the limit of the new format. For example, if Tot Net Format is xxxxx.xx and the present total is 50000.00, changing Tots EGU from Gal to Lit will cause the rescaled total to exceed the maximum displayable value and it will be reset to zero.*

---

**Table 9. Custom Slope**

Unit	Slope
ft <sup>3</sup>	1.3368e-1
m <sup>3</sup>	3.7900e-3
barrel	2.3810e-2
Imp Gal	8.3267e-1

\* 42 gallon barrel

Slope is the quantity of the custom unit that equals one gallon; i.e.,  $0.00379 \text{ m}^3 = 1 \text{ Gallon}$ . Therefore, 0.00379 is the slope.

### Tot/Net Format

In Tot/Net Format, from the eight choices in the menu, select the format of your forward, reverse, and net total from #####.### to #####.e4.

**NOTES:**

- 1. Changing this parameter can change the total to zero if the total exceeds the limit of the new format. For example, if Tot/Net Format was configured as xxxxxx.x and present total was 123456.7 but then the Rate Format was changed to xxxxx.xx, the totalizer would reset to zero.*
  - 2. If you plan to use the output pulse in Totalizer mode, the size of each pulse will be the equivalent of 1 digit in the rightmost decimal position of the displayed total.*
- 

### Gr Tot Format

In Gr Tot Format, from the eight choices in the menu, select the format of your grand total from #####.### to #####.e4.

---

*NOTE: Changing this parameter can change the total to zero if the total exceeds the limit of the new format. For example, if Gr Tot Format was configured as xxxxxx.x and present total was 123456.7 but then the Gr Tot Format was changed to xxxxx.xx, the totalizer would reset to zero.*

---

## Reset Totals

This Setup parameter offers the opportunity to reset the totalizers to zero. To reset the totalizers, answer yes to the question “Reset All Tots?”

## Setup of Outputs

The structural diagram of the Outputs menu is located on Figure A-8 through Figure A-10 of Appendix A beginning on page 40.

## Output Mode

In this parameter, specify your output as Digital or Analog. Specify Analog if you want an analog 4 to 20 mA signal. In this mode, a 600 baud digital signal is superimposed over the 4-20 mA signal for communication with an HHT and/or PC10. Specify Digital if you want to have a 4800 baud digital signal for I/A Series system communication.

If you selected Digital, further specify Unidirectional or BiDirectional flow. If you selected Analog, further specify Unidirectional, Unidirectional Multi-Range, BiDirectional Dual Range, or Bidirectional Split Range.

For Unidirectional Multi-Range, both contact inputs must be set to “Multi-Range” to select from one of three ranges. In Bidirectional Dual Range the transmitter outputs a 4-20 mA current based on the URV for either forward or reverse flow, as appropriate, and uses a contact output to indicate flow direction. In either case (Unidirectional Multi-Range or BiDirectional Dual Range), the output is 4 mA at zero flow and 20 mA at the URV. BiDirectional Split Range causes forward flow to output 12 to 20 mA and reverse flow to output 12 to 4 mA. Zero flow is 12 mA.

## Range Info

If you selected Digital Output and Unidirectional mode, specify the Forward URV.

If you selected Digital Output and BiDirectional mode, specify the Forward URV and the Reverse URV.

If you selected Analog Output and Unidirectional mode, specify the Forward URV.

If you selected Analog Output and Unidirectional Multi-Range mode, specify the URV for each of three ranges.

If you selected Analog Output and BiDirectional Dual Range mode, specify the Forward URV and the Reverse URV.

If you selected Analog Output and BiDirectional Split Range mode, specify the Forward URV and the Reverse URV.

---

*NOTE: In each case, the URV must be within the minimum and maximum URV limits of the flowtube (see appropriate flowtube Master Instruction in “Reference Documents” on page 2). The largest number that can be entered is limited by the “Rate Format” selection. The units for the URVs are defined by the “Rate Display/Rate GU” selection.*

---

## Pulse Out

In this parameter, specify the Pulse Output as Off, Pulse Rate, or Pulse Total.

---

*NOTE: The Pulse Output is only unidirectional. Therefore it should be configured OFF if you have specified BiDirectional flow.*

---

If you selected Pulse Rate, specify the Pulse Out URV within the minimum and maximum URV limits of the flowtube (see note above) in the Rate EGU units previously configured and Rate Max Freq at that rate from the menu as 1000, 2000, 5000, or 10000 Hz.

---

*NOTE: Changing Rate Max Freq can affect the Pulse Preset in the Calibration Menu. For example, if Rate Max Freq was configured as 5000 and Pulse Preset as 4000 but then the Rate Max Freq was changed to 1000. When you accessed Pulse Preset again, you would be warned that the preset value exceeded the maximum. The display would show a value of 1000.0, the maximum allowable value.*

---

If you specified Pulse Total, specify the Tot Max Freq from the menu as 10 or 100 Hz. This limits the frequency of the pulses to protect your counting device.

## Rate Out Damp

In this parameter, specify the damping rate for the analog output and the pulse rate output. It is the time required to go from zero to 90% of a change. It can be set from 0.0 to 99.9 seconds. If the Noise Reduction parameter is enabled, it also affects the digital output indirectly since the rate output damping determines the timing of the noise reduction algorithm.

## Relay Out 1 and Relay Out 2

In RO n FUNCTION, specify the function of each of the output relays from the menu. Choices are shown in Table 10.

**Table 10. Function of Output Relays**

Function	Description
Off	Relay not used.
Alarm	Relay activates upon alarm as configured.
Alarm & Diagnostics	Relay activates upon configured alarms or any diagnostic condition.
Diagnostics	Relay activates upon any diagnostic condition.
Flow Direction	Relay activates upon change in flow direction.



If you specified Alarm or Alarm & Diagnostics, further specify the alarm from the menu as High Rate, Low Rate, High Fwd Tot 1, High Fwd Tot 2, Empty Pipe, or Any Alarm.

In RO n OPERATION, specify each relay as normally open or closed.

In RO n SUPPRESSION, specify the suppression feature for each relay as Yes or No. The suppression feature applies only to alarms. When present, it suppresses reactivation of an alarm once it is acknowledged until the alarm condition is cleared and reoccurs.

## Setup of Alarms

The structural diagram of the Alarms menu is located on Figure A-11 of Appendix A on page 43.

First, specify the alarms feature as On or Off.

---

*NOTE: Shutting alarms Off does not acknowledge existing alarms.*

---

If On, proceed to configure the following alarm parameters:

### High Rate and Low Rate

Set each of these alarms as On or Off. If On, specify the set point and the amount of dead-band between 0 and 999999 in the Rate EGU units previously configured. Alarm rates are absolute values so use care in applying them to bidirectional flow.

### High Fwd Tot 1 and High Fwd Tot 2

Set each of these alarms as On or Off. If On, specify the set point between 0 and 999999 in the TOTS EGU units previously configured.

### Empty Pipe

The intent of the Empty Pipe Detection feature is explained in “Empty Pipe Detection” on page 31.

---

*WARNING: Do not take any action that can cause danger to personnel or damage to equipment based on the assumption that a pipe is empty or full because of an Empty Pipe Detection indication.*

---

Set this alarm as On or Off.

### Rate Response

Specify if an alarm will cause the analog output and pulse rate output to Go (fully) Down-scale, Go (fully) Upscale, or have No Effect. Analog output limits are 3.8 mA and 22.0 mA (12.0 mA and 22.0 mA. in Split Range). Pulse rate limits are 3 Hz and 110% of the configured maximum pulse rate.

---

*NOTE: There is a hierarchy of precedence in driving the output up or down scale. The Signal Lock takes precedence over Diagnostics which takes precedence over Alarms. Therefore, if an alarm condition has caused the output to be driven upscale, a diagnostic condition could override the first action and drive the output downscale.*

---

## Display Respon

Specify if the display icon, upon an alarm condition, is to Blink or Don't Blink.

## Alarm Clear

Set this parameter to Manual if acknowledging an alarm is mandatory. Set it to Auto if acknowledging an alarm is not required if the alarm condition self corrects.

## Setup of Diagnostics

The structural diagram of the Diagnostics menu is located on Figure A-12 of Appendix A on page 44.

## Rate Response

Specify if a diagnostic error will cause the analog output or pulse rate output to Go (fully) Downscale or Go (fully) Upscale.

---

*NOTE: There is a hierarchy of precedence in driving the output up or down scale. The Signal Lock takes precedence over Diagnostics which takes precedence over Alarms. Therefore, if an alarm condition has caused the output to be driven upscale, a diagnostic condition could override the first action and drive the output downscale.*

---

## Display Respon

Specify if the display, upon an alarm condition, is to Blink or Don't Blink.

## Setup of Identity

The structural diagram of the Identity menu is located on Figure A-13 of Appendix A on page 44.

Identify the following with the maximum number of alphanumeric characters listed. Use the characters listed in Table 7.

Tag Number	12 Characters
Location	14 Characters
Tag Name*	14 Characters
Device name*	6 Characters
Tube MS Code	32 Characters
Tube Serial Num	16 Characters

---

*\*NOTE: Setup of Passcodes Tag Name and Device Name only apply if Output Mode was configured as Digital.*

---

## Setup of Passcodes

The structural diagram of the Passcodes menu is located on Figure A-14 on page 45.

Passcodes may be configured On or Off. If you specify Off, there is no passcode protection. If you specify On, you may configure each of two passcodes to protect:

- ◆ Setup (setup functions protected, ability to reset totals not protected)
- ◆ Totals Reset (ability to reset totals protected, ability to change setup functions not protected)
- ◆ Setup and Totals (both functions protected).

An example of how this can be used is that one passcode could be given to some operators to enable them to reset totals but not change the configuration of the transmitter. Other operators could be given another passcode to enable them to reset totals and change the configuration.

The sequence of this setup procedure is to specify the function of Passcode 1 and then its passcode. The passcode can be any four digit number between 0000 and 9998. When you have entered it, the display will ask you, "Are You Sure?". Use the right arrow key to accept the new passcode and the left arrow key to cancel it. After you have completed the procedure for Passcode 1, repeat it for Passcode 2.

## Setup of Transmitter

The structural diagram of the Transmitter menu is located on Figure A-15 and Figure A-16 in Appendix A beginning on page 46.

### Xmtr Mode

Specify if you want the transmitter to be on-line or off-line. This parameter could read calibrate or override if someone has changed the mode with an HHT Hand-Held Terminal, PC10 Configurator, or I/A Series Workstation. However, there is no need to set this parameter to anything other than on-line or off-line.

### Line Frequency

Specify the line frequency as 50 or 60 Hz. If you are using a dc powered transmitter, select the local ac power frequency to ensure optimal performance.

## Flow Direction

Specify the flow direction as shown in Table 11.

You must select BiDir if, and only if, you selected a BiDir flow mode in the Output section of Setup.

Select “positive” if the forward flow direction agrees with the flow direction arrow on the tube. Select “reverse” if the forward flow direction is opposite from the flow arrow.

**Table 11. Flow Direction**

Direction	Description
Positive	Forward flow is in direction of arrow on flowtube and unidirection flow mode was selected in the output section of setup.
Reverse	Forward flow is in direction of arrow on flowtube and unidirection flow mode was selected in the output section of setup.
BiDir Positive	Forward flow is in direction of arrow on flowtube and bidirection flow mode was selected in the output section of setup.
BiDir Reverse	Forward flow is in direction of arrow on flowtube and bidirection flow mode was selected in the output section of setup.

## Contact Input 1 and Contact Input 2

For each of the two contact inputs, specify On or Off. If On, specify the Function as one of the choices shown in Table 12 and then the Operation as Normally Closed or Normally Open.

If you have specified Analog Unidirectional Multi-Range output, you *must* select Multi-Range for both CI1 and CI2. The external connections to these contacts must be so arranged that at least one of them is always in the active state; it is considered an error condition for both inputs to be in the off state. If you have *not* specified Analog Unidirectional Multi-Range output, you should *not* select Multi-Range as the function of either of the contact inputs.

**Table 12. Contact Input Functions**

Function	Description
Ack Alarm	Acknowledges an alarm, eliminates the need to do this manually.
Reset Net Tot	Resets the Forward, Reverse, and Net Totals.
Reset Grand Tot	Resets the Grand Total.
Reset All Tot	Resets all totals.
Multi-Range	Switches the range in a Multi-Range configuration.
Signal Lock	Drives the outputs to zero.


## Noise Reduction

The noise reduction feature slows the initial output response to a change. See Figure 5. Specify the noise reduction feature as On or Off, and use the Rate Out Damp selection to control the amount of Noise Reduction action.

---

***NOTE: Noise reduction is applied to the Display, 4-20 mA, and Digital outputs.***

---



***Figure 5. Noise Reduction***

## Empty Pipe Detection

The intent of the Empty Pipe Detection feature is to prevent false flow readings that can occur with empty pipe conditions. Without this feature, the input to the transmitter could become an open circuit and the output could drift. With this feature, the empty pipe detection circuit prevents output drift by monitoring the conductivity between electrodes and forcing the output to zero if the conductivity falls below a predetermined level. The feature does not reveal a partially full condition if the electrodes remain covered with fluid and does not indicate how empty a pipe is if the electrodes are exposed. Also, fouling of the electrodes could cause a false empty pipe condition and coating of the electrodes with a viscous fluid could cause a significant lag before an empty pipe condition is recognized.

---

***WARNING: Do not take any action that can cause danger to personnel or damage to equipment based on the assumption that a pipe is empty or full because of an Empty Pipe Detection indication.***

---

Specify the Empty Pipe detector as On or Off. Then, with the pipe full, perform the calibration procedure which determines the set point by following the structure diagram on Figure A-16 located on page 47.

## Setup of Calibration

The structure diagram of the Calibration menu is located on Figure A-17 in Appendix A beginning on page 48.

## Meter Factor

Enter the meter factor of the flowtube. Use the form `#####e+##`. For example, a meter factor of 18.22 should be entered as 1.8220e+01. For determination of IMT25 Meter Factor, see page 5.

## Analog Out Cal

This parameter allows you to tune the 4 mA and 20 mA output values. The procedure is as follows:

1. Connect a precision milliammeter in the output loop.
2. With 4 mA ADJUST on the first line of the display, use the  $\Delta$  and  $\nabla$  keys to select an adjustment step size of 0.5, 0.05, or 0.005 mA. Then, use the left or right arrow keys to execute the adjustment in the lower or higher direction respectively.
3. Repeat Step 2 until your milliammeter reads 4 mA. Then using the  $\Delta$  and  $\nabla$  keys, go to Done and press either the left or right arrow key.
4. Repeat Steps 2 and three for 20 mA.

---

*NOTE: This parameter only appears if transmitter is in Analog Output mode.*

---

## Preset Outputs

This parameter allows you to override the normal output with a particular output. If the transmitter is in Analog mode, you may preset the output between 3.80 and 22.0 mA; If in Digital mode, between 0 and 999999 in the configured Rate EGU units; If in Pulse Rate mode, between 0 and the maximum pulse rate as configured; and if in Pulse Total mode, between 0 and the maximum pulse rate as configured. You can preset this value and configure it Off until you are ready to use it. You may change the configuration to On at the appropriate time.


---

*NOTE: Presets have a lower priority than Signal Lock, Diagnostics, and Alarms. If the transmitter is in Signal Lock or an alarm or diagnostic is active and the output action for the active condition is anything other than No Effect, the preset will not actually control the output until the overriding condition goes away.*

---


# Appendix A. Structure Diagrams

This appendix contains structure diagrams that illustrate the menu structure of the IMT25 Transmitter and show how you can use the local display and keypad to get from one point to another in the structure. These diagrams and the configuration worksheets included in Appendix B can be invaluable tools in configuring and troubleshooting your transmitter.



*Figure A-1. Structure Diagram – Top Level Menu*

## Measurements Menu Structure



*Figure A-2. Structure Diagram – Measurements Menu*



### Status Menu Structure




Figure A-3. Structure Diagram – Status Menu

## Identity Menu Structure

TAG NUMBER  
 ABCDEF123456  
 12 alphanumeric characters

LOCATION  
 ABCDEFGH1234567  
 14 alphanumeric characters

*If XMTR is DIGITAL output mode:* - - - - -

TAG NAME  
 ABCDEFGH1234567  
 14 alphanumeric characters

DEVICE NAME  
 ABC123  
 6 alphanumeric characters - - - - -

XMTR MS CODE  
 ABCDEFGH12345678  
 16 alphanumeric characters

XMTR SERIAL NUM  
 ABCDEFGH12345678  
 16 alphanumeric characters

TUBE MS CODE  
 ABCDEFGH1234567 ▶  
 32 alphanumeric characters

TUBE SERIAL NUM  
 ABCDEFGH1234567  
 16 alphanumeric characters


SOFTWARE VER  
 ###.###  
 7 alphanumeric characters

The IDENTITY menu allows viewing only, no editing. Use the Δ and ∇ arrow keys to move through the structure.

On strings over 16 characters, left or right arrow icons indicate off-screen characters.

**Figure A-4. Structure Diagram – Identity Menu**

### Level 2 Setup Menu Structure



**Figure A-5. Structure Diagram – Setup Menu**

### Level 3 System Menu Structure




Figure A-6. Structure Diagram – System Menu

### Level 3 System Menu Structure (Cont.)




Figure A-7. Structure Diagram – System Menu (Cont.)

### Level 3 OUTPUTS Menu Structure




Figure A-8. Structure Diagram – Outputs Menu

### Level 3 OUTPUTS Menu Structure (Cont.)




Figure A-9. Structure Diagram – Outputs Menu (Cont.)

### Level 3 OUTPUTS Menu Structure (Cont.)




Figure A-10. Structure Diagram – Outputs Menu (Cont.)



### Level 3 ALARMS Menu Structure




Figure A-11. Structure Diagram – Alarms Menu

### Level 3 DIAGNOSTICS Menu Structure




Figure A-12. Structure Diagram – Diagnostics Menu

### Level 3 IDENTITY Menu Structure





Figure A-13. Structure Diagram – Identity Menu

### Level 3 PASSCODES Menu Structure



**Figure A-14. Structure Diagram – Passcodes Menu**

### Level 3 TRANSMITTER Menu Structure




Figure A-15. Structure Diagram – Transmitter Menu

### Level 3 TRANSMITTER Menu Structure (Cont.)




Figure A-16. Structure Diagram – Transmitter Menu (Cont.)

### Level 3 CALIBRATION Menu Structure




Figure A-17. Structure Diagram – Calibration Menu

# Appendix B. Configuration Worksheets

This appendix contains information that will help you configure your IMT25 Transmitter. This page defines the content of the worksheets. Subsequent pages contain the actual configuration worksheets.

Identifies the specific structure diagram figure that contains the parameter

Prompts to parameters in the order in which they appear as you step through the menu structure

Available options or limits for each parameter

Standard factory configuration as shipped from Foxboro

Space for you to record your specific configuration

Additional information and space for your notations

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Default Factory Configuration	User Configuration	Remarks and Notes

---

*NOTE: Shaded areas in configuration worksheets indicate options that are available only if the preceding option has been selected.*

---

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
<b>3 SYSTEM</b>					
A-6	<b>DEFAULT SCREEN</b>				
	Default Screen	Rate EGU, Rate %Range, Forward Total, Reverse Total, Net Total, Grand Total, Dual Display	Rate EGU		
	Dual Display?	On, Off	Off		
	If On:				
	Disp Line 1?	Rate EGU, Rate %Range, Forward Total, Reverse Total, Net Total, Grand Total	Rate EGU		
	Disp Line 2?	Rate EGU, Rate %Range, Forward Total, Reverse Total, Net Total, Grand Total	Rate EGU		
	Rate Display	GPM, GPH, GPD, LPM, LPH, LPD, Custom	GPM		
	If Custom:				
	Custom Units	Enter up to 6 alphanumerics	---		
	Custom Slope	Enter up to 9 digits	1		
	Rate Format	###000. ####00. #####0. #####.# ####.## ###.### ##.####	#####.#		
	Rate Damping	0.0 to 99.9 seconds	3.0		



Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-7	TOTALIZER				
	Totalizer On?	Off, On	Off		Changing any totalizer parameter resets all totals and causes warning message to appear.
	If On:	---	---		
	Tots EGU:	Gal, Lit, Custom	Gal		
	If Custom:	---	---		
	Tots Cust Units	Enter up to 6 alphanumerics:	---		
	Tots Cust Slope	Enter up to 9 digits from 1.0e-10 to 1.0e+10	1		
	Tot/net Format	Select 1 of 8 formats	#####.		
Gr Tot Format	Select 1 of 8 formats	#####.			

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-8	3 OUTPUTS				
	Output Mode?	Digital, Analog	Per Model Code		
	If Digital:	---	---		
	Output Mode?	UniDir, BiDir	UniDir		
	If Analog:	---	---		
	Output Mode?	UniDir, Uni Multi-Rng, BiDir Dual Rng, BiDir Split Rg	UniDir		
	If Analog AND Uni Multi Rng:	---	---		
	Range Info:	---	---		
	Multi-Rang URV1	0 to 999999	100		
	Multi-Rang URV2	0 to 999999	200		Must match value below marked **
	Multi-Rang URV3	0 to 999999	300		
	If digital AND UniDir OR Analog AND UniDir:	---	---		
	Range Info:	---	---		
	Forward URV	0 to 999999	100		
	If Digital AND BiDir OR Analog AND BiDir Dual Rng OR Analog AND BiDir Split Rg	---	---		
	Range Info:	---	---		
	Forward URV	0 to 999999	100		
Reverse URV	0 to 999999	200		** Must match value of Multi-Range URV2 above	

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-9	3 OUTPUTS (cont.)				
	Pulse Out Mode	Off, Pulse Rate, Pulse Total	Off		Pulse output (rate or total) is always unidirectional.
	If Pulse Rate:	- - -	- - -		
	Pulse Out URV	0 to 999999	100		
	Rate Max Freq	1000, 2000, 5000, or 10000 Hz	2000 Hz		
	If Pulse Total	- - -	- - -		
	Tot Max Freq	10 Hz, 100 Hz	10 Hz		
	Rate Out Damp	0 to 99.9 seconds	3.0 seconds		Rate output damping applies to analog and pulse rate outputs. It also controls the noise reduction action.

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-10	Relay Out 1	---	---		
	RO1 Function:	Off, Alarm, Alarm & Diag, Diagnostics, Flow Direction	Off		
	If Alarm or Alarm & Diag	---	---		
	RO1 Alarm?	High Rate, Low Rate, High Fwd Tot 1 High Fwd Tot 2 Empty Pipe Any Alarm	High Rate		
	RO1 Operation:	Normally Closed, Normally Open	Normally Open		
	RO1 Suppress:	No, Yes	No		
	Relay Out 2	---	---		
	RO2 Function:	Off, Alarm, Alarm & Diag, Diagnostics, Flow Direction	Off		
	If Alarm or Alarm & Diag	---	---		
	RO2 Alarm?	High Rate, Low Rate, High Fwd Tot 1 High Fwd Tot 2 Empty Pipe Any Alarm	Low Rate		
	RO2 Operation:	Normally Closed, Normally Open	Normally Open		
	RO2 Suppress:	No, Yes	No		

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-11	3 ALARMS				
	Alarms On?	Off, On	Off		
	If On:		---		
	High Rate:	---	---		
	Hi Alarm On?	Off, On	Off		
	If On:	---	---		
	Hi Alm Setpt	0 to 999999	100		
	Hi Alm Dband	0 to 999999	1.00		
	Low Rate:	---	---		
	Low Alarm On?	Off, On	Off		
	If On:	---	---		
	Low Alm Setpt	0 to 999999	1.0		
	Low Alm Dband	0 to 999999	0.5		
	High Fwd Tot 1:	---	---		
	Tot 1 Alarm On:	Off, On	Off		
	Tot 1 Alm Setpt	0 to 9999999	100000		
	High Fwd Tot 2:	---	---		
	Tot 2 Alarm On:	Off, On	Off		
	Tot 2 Alm Setpt	0 to 9999999	100000		
	Empty Pipe	---	---		
EPD Alarm On?	Off, On	Off			
Rate Response?	Go Downscale Go Upscale	Go Down- scale			
Display Response?	Don't Blink, Blink	Don't Blink			
Alarm Clear?	Manual Auto	Auto			
A-12	3 DIAGNOSTICS				
	Rate Response?	Go Downscale Go Upscale	Go Down- scale		
	Display Respon?	Don't Blink, Blink	Blink		

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-13	<b>3 IDENTITY</b>				
	Tag Number	Enter up to 12 alphanumeric characters	Tagnumber		
	Location	Enter up to 14 alphanumeric characters	Location		
	If XMTR is Digital Output Mode:				
	Tag Name	Enter up to 14 alphanumeric characters	Tagname		
	Device Name	Enter up to 6 alphanumeric characters	Devicename		
	Tube MS Code	Enter up to 32 alphanumeric characters	Tube MS		
	Tube Serial Num	Enter up to 16 alphanumeric characters	Tube S/N		
A-14	<b>3 PASSCODES</b>				
	Passcode 1	Off, On	Off		
	If On:	- - -	- - -		
	Pass 1 Protect?	Setup, Totals Reset, Setup & Totals	Setup		
	Passcode 1	0000 to 9998	- - -		Following entry, confirmation screen appears. Press "Left" to cancel, "Right" to accept.
	Passcode 2	Off, On	Off		
	If On:	- - -	- - -		
	Pass 2 Protect?	Setup, Totals Reset, Setup & Totals	Setup		
Passcode 2	0000 to 9998	- - -		Following entry, confirmation screen appears. Press "Left" to cancel, "Right" to accept.	

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-15	3 TRANSMITTER				
	Xmtr Mode?	Off-Line, On-Line	---		A change to On-Line causes a quickstart with return to here in the local display.
	Line Frequency?	50 Hz, 60 Hz	60 Hz		
	Flow Direction?	Positive, Reverse, BiDir Positive, BiDir Reverse	Positive		
	CI 1 Function?	Off, Ack Alarm, Reset Net Tot, Reset Gr Tot, Reset All Tot, Multi-Range, Signal Lock	Off		
	If NOT Off:	---	---		
	CI 1 Operation?	Normally Closed, Normally Open	Normally Open		
	CI 2 Function?	Off, Ack Alarm, Reset Net Tot, Reset Gr Tot, Reset All Tot, Multi-Range, Signal Lock	Off		
	If NOT Off:	---	---		
	CI 2 Operation?	Normally Closed, Normally Open	Normally Open		
A-16	Noise Red On?	Off, On	On		
	Empty Pipe Det				
	EPD Setup	Off, On	Off		
	Calculate Setpt	Press→ if tube is filled. Press→ to start.	---		Completion indicated by Successful or Fail message.

Structure Diagram	Prompt/Parameter	Options or Parameter Limits	Factory Default Configuration	User Entry or Selection	Remarks/Notes
A-17	3 CALIBRATION				
	Meter Factor	In form #.#####e+##	1.20000e+01		
	If Xmtr is Analog Output Mode:				
	Analog Out Cal	---	---		
	4 mA Adjust	Done, 0.5 mA, 0.05 mA, 0.005 mA	Done		Left and right arrow keys decrement and increment the step size picked with the Up and Down arrow keys.
	20 mA Adjust	Done, 0.5 mA, 0.05 mA, 0.005 mA	Done		Left and right arrow keys decrement and increment the step size picked with the Up and Down arrow keys.
	Preset Outputs	---	---		
	Analog Preset	3.80 to 22.00 mA in form ##.##	---		
	Analog Preset On	Off, On	Off		
	If Xmtr is Digital Output Mode:	---	---		
	Rate Preset	0 to 999999	---		
	Rate Preset On	Off, On	Off		
	If Pulse Out Mode is Pulse Rate	---	---		
	Pulse Preset:	0 to 10000 Hz	---		
	Pulse Preset On	Off, On	Off		
	If Pulse Out Mode is Pulse Total	---	---		
	Pulse Preset:	0 to 10000 Hz	---		
	Pulse Preset On	Off, On	Off		



# *Index*

## *A*

Acknowledging Alarms 11  
Alarm and Diagnostic Messages 8  
Alarm Clear 28  
Alarm Display Response 28  
Alarm Rate Response 27

## *C*

Calibration 31  
Configuration 21  
Configuration Procedure 21  
Configuration Worksheets 49  
Contact Input 1 and Contact Input 2 30

## *D*

Default Screen 22  
Description 1  
Diagnostic Display Response 28  
Diagnostic Rate Response 28  
Display Identity 21  
Dual Display 22

## *E*

Empty Pipe Alarm 27  
Empty Pipe Detection 31

## *F*

Flow Direction 30  
Functions 1

## *H*

High Fwd Tot 1 and High Fwd Tot 2 Alarms 27  
High Rate and Low Rate Alarms 27

## *I*

Identity 18

## *K*

Keypad/Display Panel 7

## *L*

Level 2 Setup Menu 22  
Level 3 System Setup Menu 22  
Line Frequency 29

## *M*

Measurements 15

Mode, Xmtr 29

**N**

Noise Reduction 31

**O**

On-Line HELP 8

On-Line Help 14

Operation 7, 21

**P**

Pulse Out 26

**R**

Range Info 25

Rate Display 22

Rate Out Damp 26

Reference Documents 2

Relay Out 1 and Relay Out 2 26

Resetting Totals and Empty Pipe Count 12

**S**

Setup 18

Setup, Alarms 27

Setup, Calibration 31

Setup, Diagnostics 28

Setup, Identity 28

Setup, Outputs 25

Setup, Passcodes 29

Setup, System 22

Setup, Transmitter 29

Status 16

Structure Diagrams 33

**T**

Top Level Menu 14

Totalizer 24

**V**

Viewing and Changing Data 12

ISSUE DATES

MAR 1996

MAY 1996

SEP 1996

Vertical lines to right of text or illustrations indicate areas changed at last issue date.

**The Foxboro Company**

33 Commercial Street  
Foxboro, MA 02035-2099  
United States of America  
<http://www.foxboro.com>  
Inside U.S.: 1-888-FOXBORO  
(1-888-369-2676)

Outside U.S.: Contact your  
local Foxboro Representative.  
Facsimile: (508) 549-4992

**A Siebe Group Company**

Foxboro, FoxCom, and I/A Series are trademarks of The Foxboro Company.  
Siebe is a registered trademark of Siebe, plc.

Copyright 1996 by The Foxboro Company  
All rights reserved

MB 100

Printed in U.S.A

0996